

# State of the art ambient ultrafine particle monitoring: the blind spot of current methods

Tiwari, A.J., Schmitt, S.H., Tritscher, T., Koczak, J.S., **Wright, T. P.**  
National Ambient Air Monitoring Conference 2022

# Air pollution and health



Ambient air monitoring efforts play a critical role in:

- Alerting us to air pollution hazards exceeding established levels (regulatory scale)
- Creating datasets that help to identify new hazards / levels (research scale)



# Air pollution and health




Ambient air monitoring efforts play a critical role in:

- Alerting us to air pollution hazards exceeding established levels (regulatory scale)
- Creating datasets that help to identify new hazards / levels (research scale)

Health effects  
of air pollution

Causative  
constituents



# PM2.5 is a health hazard, is regulated



Ambient PM2.5 exposure associated with:


- Respiratory illnesses
- Cardiovascular diseases
- Globally, ~3.5 million cases of COPD and ~220,000 lung cancer deaths annually

- *Miller et al 2018 and references therein*

PM2.5 accounts for > 90% of monetized social costs of air pollution

- *Heo et al 2016 and references therein*


# Particulate Matter (PM): PM<sub>10</sub> and PM<sub>2.5</sub>



## NAAQS

- PM<sub>10</sub>
  - 150  $\mu\text{g}/\text{m}^3$  (24 hr)
- PM<sub>2.5</sub>
  - 12  $\mu\text{g}/\text{m}^3$  (1 yr)
  - 35  $\mu\text{g}/\text{m}^3$  (24 hr)
- Standardized methods (FRM and FEM) [list](#)

# Particulate Matter (PM): zooming in



- **PM<sub>0.1</sub>**
  - 100 nm diameter = the upper end of the “ultrafine particles” (UFP) range
  - Includes particles down to 1 nm

# Where do UFP's come from?




## Emitted as primary particles

- Transportation, industry, biomass burning, etc.

## Via nucleation of gas-phase precursors

- Natural precursors
- Anthropogenic precursors



Zhang et al 2020 Fig 2b  
[Open Access license](#)




# UFPs deposit, translocate in the human body



## In humans:

- Exogenous nanoparticles found in human lung fluid (pleural effusion) (Lu *et al* 2020)



Lu et al 2020 Fig 1a  
[Open Access license](#)




# UFPs deposit, translocate in the human body



## In humans:

- Exogenous nanoparticles found in human lung fluid (pleural effusion) (Lu *et al* 2020) →
- Human volunteers inhaled 5 nm and 30 nm gold nanoparticles (Miller *et al* 2017):
  - detected in blood and urine within 24 h,
  - still present after 3 months
  - levels were greater for 5 nm than for 30 nm




Lu et al 2020 Fig 1a  
[Open Access license](#)

# Health hazards: UFP is distinct from PM2.5



- UFP ( $PM_{0.1}$ ) may contribute to disease via molecular and/or epigenetic mechanisms (Traboulsi *et al* 2017) →
- Perinatal exposure to UFP's linked to onset of asthma in children, independent of  $PM_{2.5}$  (Lavigne *et al* 2019)




# UFP and NAAQS: hiding in plain sight



Many established FRMs, FEMs are insufficiently sensitive to UFPs:

- Gravimetric
- Light scattering
- Beta attenuation
- TEOM




# UFP and NAAQS: hiding in plain sight



Many established FRMs, FEMs are insufficiently sensitive to UFPs:

- Gravimetric
- Light scattering
- Beta attenuation
- TEOM




# UFP and NAAQS: hiding in plain sight



Many established FRMs, FEMs are insufficiently sensitive to UFPs:

- Gravimetric
- Light scattering
- Beta attenuation
- TEOM

*Particles smaller than 190 nm make up:  
~50% of the mass, but  
~92% of the particle count*



# UFP and NAAQS: hiding in plain sight



Many established FRMs, FEMs are insufficiently sensitive to UFPs:


- Gravimetric
- Light scattering
- Beta attenuation
- TEOM

*Particles smaller than 190 nm make up:*

*~50% of the mass, but*

*~92% of the particle count*

**→ 8% of the number contributes 50% of the mass**




# UFPs and NAAQS: hiding in plain sight



- PM2.5 does include UFPs, but...
- Identical re: mass  $\neq$  identical in every way

Two real ambient samples		
Sample	PM0.7 ( $\mu\text{g}/\text{m}^3$ )	Number conc. ( $\#/ \text{cm}^3$ )
-----	12.3	$4.47 \times 10^3$




# UFPs and NAAQS: hiding in plain sight



- PM2.5 does include UFPs, but...
- Identical re: mass  $\neq$  identical in every way

Two real ambient samples		
Sample	PM0.7 ( $\mu\text{g}/\text{m}^3$ )	Number conc. ( $\#/ \text{cm}^3$ )
-----	12.3	$4.47 \times 10^3$
—————	12.3	$2.21 \times 10^4$





# Suitable monitoring techniques for UFP's



## DON'Ts

- Be mass-based
  - Gravimetric
- Be biased toward larger particles
  - Light scattering
  - Beta attenuation
  - TEOM



## DOs

- Count (number-based)
- Measure particle size

# UFP Monitoring: TSI in research networks



## ▪ ACTRIS

- 22 countries, 79 observational platforms
- Data at <https://actris.nilu.no/>
  - 42 sites – particle number
  - 58 sites – particle size distributions



# UFP Monitoring: standardization in EU



- CEN: standardization body in EU

CEN/TS #	Scope	Technology			TSI Product
		Principle	Specific requirements		
16976	Number Concentration	CPC	Butanol-based	D50: 10 nm (standard is changing from 7 to 10 nm)	
17434	Size Distribution	Electrical Mobility sizing	DMA: 10-800 nm (single scan)	CPC: compliant w/ above	

# UFP Monitoring: standardization in EU



- CEN: standardization body in EU




CEN/TS #	Scope	Technology			TSI Product
		Principle	Specific requirements		
16976	Number Concentration	CPC	Butanol-based	D50: 10 nm (standard is changing from 7 to 10 nm)	CPC 3750
17434	Size Distribution	Electrical Mobility sizing	DMA: 10-800 nm (single scan)	CPC: compliant w/ above	SMPS

# UFP Monitoring: counting single particles



## Condensation Particle Counter (CPC)

- Established technology for many applications
  - ambient air, filter testing, cleanrooms, etc.
- Concept
  - Condense liquid onto particles to grow them large enough for laser detection




# UFP Monitoring: counting single particles



## Condensation Particle Counter (CPC)

- Established technology for many applications
  - ambient air, filter testing, cleanrooms, etc.
- Concept
  - Condense liquid onto particles to grow them large enough for laser detection
- Key instrument specifications:
  - D50: how small of particles can be detected
  - Concentration range
  - Other considerations:
    - Butanol vs. water as working fluid
    - Inlet flow rate(s)



# UFP Monitoring: counting single particles



- CEN compliant Condensation Particle Counter (CPC) 3750
- Key specs, attributes:
  - D50 = 7 nm (10 nm also available)
  - Concentration range: up to 100,000 #/cm<sup>3</sup>
  - Other considerations:
    - Working fluid: butanol
    - Inlet flow rate: 1 L/min
- Other models also available
  - Ex. 3789 uses **distilled water**




# UFP Monitoring: sizing ultrafine particles



- Optical particle sizing has a lower limit ~100 nm  
→ not suitable for UFP
- Electrical mobility: the ability of a (charged) particle to move in an electric field
  - ISO 15900

$$Z_p = \frac{\text{Particle Velocity}}{\text{Electric Field Strength}} = \frac{v}{E} = \frac{n_p e C}{3\pi\mu D_p}$$






# UFP Monitoring: sizing ultrafine particles



- Differential Mobility Analyzer (DMA): hardware component that performs electrical mobility size determination
- Well-established technology
  - used at NIST to measure particle size standards
- Annular, interior space has electric field due to high voltage on inner rod
- Can be used to:
  - emit just one size (voltage constant), or
  - scan across particle sizes (voltage changes)

Monodisperse Aerosol Out




# UFP Monitoring: Scanning Mobility Particle Sizer (SMPS™)




1) Polydisperse aerosol sample into DMA...



# UFP Monitoring: Scanning Mobility Particle Sizer (SMPS™)





# UFP Monitoring: Scanning Mobility Particle Sizer (SMPS™)



# UFP Monitoring: Scanning Mobility Particle Sizer (SMPS™)



# UFP Monitoring: Scanning Mobility Particle Sizer (SMPS™)



Wide-Range DMA: .....  
10-800 nm in a single scan

# UFP Monitoring: sampling

Removal of particles  $> 10 \mu\text{m}$ ,  $2.5 \mu\text{m}$

- Representative sampling of ambient UFPs is challenging:
  - Smaller particles – diffusional losses
  - Larger particles interfere with UFP size measurements



# UFP Monitoring: sampling

- Representative sampling of ambient UFPs is challenging:
  - Smaller particles – diffusional losses
  - Larger particles interfere with UFP size measurements

Removal of particles  $> 10 \mu\text{m}$ ,  $2.5 \mu\text{m}$

Flow is split into two streams:  
sampling and drying





# UFP Monitoring: sampling

- Representative sampling of ambient UFPs is challenging:
  - Smaller particles – diffusional losses
  - Larger particles interfere with UFP size measurements

Removal of particles  $> 10 \mu\text{m}$ ,  $2.5 \mu\text{m}$

Flow is split into two streams:  
sampling and drying

Drying flow is filtered, then  
used to dry the sample flow



# UFP Monitoring: sampling

- Representative sampling of ambient UFPs is challenging:
  - Smaller particles – diffusional losses
  - Larger particles interfere with UFP size measurements

Removal of particles  $> 10 \mu\text{m}$ ,  $2.5 \mu\text{m}$

Flow is split into two streams:  
sampling and drying

Drying flow is filtered, then  
used to dry the sample flow


Sample flow split  
among instruments



# UFP Monitoring: full solution

- Sampling System for Atmospheric Particles
  - 3750200
- CPC (total # concentration)
  - 3750 or 3789
- SMPS (size distribution)
  - 3938W50 or 3938W89
  - **Utilizes NEW:** DMA capable of 10-800 nm in a single scan
- Accessories
  - RHT3000 Humidity sensor
  - 3032 Pump

Entire solution described in [Brochure](#), [Video](#)



# UFP Monitoring: TSI in research networks




## ▪ ACTRIS

- 22 countries, 79 observational platforms
- Data at <https://actris.nilu.no/>
  - 42 sites – particle number
  - 58 sites – particle size distributions



## ▪ ASCENT

- [New monitoring network](#) in US
- 12 sites – particle size distributions



# UFP Monitoring: Summary

- UFPs are ubiquitous, come from various sources
- UFPs pose a public health hazard that is distinct from that posed by PM<sub>2.5</sub>
- Current US air quality regulations are mass-based, which leaves UFPs nearly invisible
- UFP monitoring is growing in the US; ASCENT network
- TSI offers UFP-capable instrumentation designed for continuous unattended monitoring installations



# Bibliography and Resources



1. CEN/TS 16976:2016. [Ambient air – Determination of the particle number concentration of atmospheric aerosol.](#)
2. CEN/TS 17434:2020. [Ambient air – Determination of the particle size spectra of atmospheric aerosol using a Mobility Particle Size Spectrometer \(MPSS\).](#)
3. Heo *et al.* Public Health Costs of Primary PM<sub>2.5</sub> and Inorganic PM<sub>2.5</sub> Precursor Emissions in the United States. *Environ. Sci. Technol.* 2016; 50(11):6061. <https://doi.org/10.1021/acs.est.5b06125>
4. Lavigne E, Donelle J, Hatzopoulou M, Van Ryswyk K, van Donkelaar A, Martin R, Chen H, Stieb D, Gasparrini A, Crighton E, Yasseen A, Burnett R, Walker M, Weichenthal S. Spatiotemporal Variations in Ambient Ultrafine particles and the Incidence of Childhood Asthma. *Am J Respir Crit Care Med.* 2019; 199(12):1487. <https://doi.org/10.1164/rccm.201810-1976OC>
5. Lu, D, Luo, Q, Chen, R, Zhuansun Y, Jiang J, Wang W, Yang X, Zhang L, Liu X, Li F, Liu Q, Jian G. Chemical multi-fingerprinting of exogenous ultrafine particles in human serum and pleural effusion. *Nat Commun.* 2020; 11, 2567. <https://doi.org/10.1038/s41467-020-16427-x>
6. Miller M, Raftis J, Langrish J, McLean S, Samutrtai P, Connell S, Wilson S, Vesey A, Fokkens P, Boere A, Krystek P, Campbell C, Hadoke P, Donaldson K, Cassee F, Newby D, Duffin R, Mills N. Inhaled Nanoparticles Accumulate at Sites of Vascular Disease. *ACS Nano.* 2017; 11(5):4542. <https://doi.org/10.1021/acsnano.6b08551>
7. Miller L, Xu X. Ambient PM<sub>2.5</sub> Human Health Effects—Findings in China and Research Directions. *Atmosphere.* 2018; 9(11):424. <https://doi.org/10.3390/atmos9110424>
8. Traboulsi H, Guerrina N, Iu M, Maysinger D, Ariya P, Baglolle CJ. Inhaled Pollutants: The Molecular Scene behind Respiratory and Systemic Diseases Associated with Ultrafine Particulate Matter. *International Journal of Molecular Sciences.* 2017; 18(2):243. <https://doi.org/10.3390/ijms18020243>
9. Zhang X, Lyu G, Song C, Qiao Y. Effects of Biodiesel Addition on the Physical Properties and Reactivity of the Exhaust Soot Particles from Diesel Engine. *Energies.* 2020; 13(16):4206. <https://doi.org/10.3390/en13164206>
10. Additional resources found at: [www.tsi.com/ultrafines](http://www.tsi.com/ultrafines) and [Water-based Wide-range Ambient Monitoring Scanning Mobility Particle Sizer \(SMPS\) 3938W89 | TSI](#)

# Thank you!



[timothy.wright@tsi.com](mailto:timothy.wright@tsi.com)



[andrea.tiwari@tsi.com](mailto:andrea.tiwari@tsi.com)



[justin.koczak@tsi.com](mailto:justin.koczak@tsi.com)